

NIKE 180	NIKE 280	300	301	302	A 35	3.40	3.45
			30FL	322	COMBI 230	CARRARO 420.5	CARRARO 520.5
				235			GOLDONI C.45
SLANZI DVA1000	SLANZI DVA1030	SLANZI DVA1300	VM295	VM 235 SLANZI DVA1500 SAME 982	VM 298	HR 392	VMRA394
1958-1960	1960-1964	1964-1967	1967-1974	1974-1978	1978-1984	1984-1990	1990-

NIKE 250	NIKE 320	350	351	352	42FL	
			35FL	352FL		
VM25DA/SL	VM210	VM210	VM210	VM102 VM1052	VMHR392	
1958-1960	1960-1961	1961-1966	1966-1972	1972-1979	1979-1990	

NIKE 401	453	500	3.60
	COMBI 345	CARRARO 50.5	CARRARO 620.5
	503		GOLDONI C.60
VM350DA/SL	VM103 VM103 SAME 983/2	VM1053/1	VM3105SUM
1966-1972	1972-1979	1979-1990	1990-

NIKE 400	NIKE 480	NIKE 500	553	600
	NIKE 480FL			
VM35DA/SL	VM310	VM310	VM1053SU DEUTZ F3L912	VM1053SU
1960-1961	1961-1965	1965-1970	1970-1974	1974-1984

654	700
VM104 DEUTZ F42912	VM1054SU
1970-1974	1974-1982

3.65

CARRARO 720.5

PERKINS 4.236DR

1981-1985

3.55

SOLO 4 PROTOTIPI

PERKINS 3.177

1982-1986

3.75

CARRARO 820.5

PERKINS LD4.236

1980-1984

T. 3.85

CARRARO 920.5

PERKINS T4.236

1980-1984

SIRIO 4RM

VMHR392A

1978-1980

VEGA 4RM

SOLO ALCUNI PROTOTIPI

VM298SV

1979-1981
