



GRUPPI FILTRI NAFTA - Fuel filter groups

- FNA0004** : FIGG.2-3-4-5-6-7-9-10-19;
 FNA0005 : FIGG.2-3-4-5-6-7-10-15-19;
 FNA0006 : FIGG.2-3-4-5-6-7-9-10-16;
 FNA0013 : FIGG.1-3-4-5-6-7-9-10-16;
- FNA0014** : FIGG.1-3-4-5-6-7-10-15-16;
 FNA0018 : FIGG.1-3-11-25-26;
 FNA0020 : FIGG.1-15-17;
 FNA0024 : FIGG.1-7-9-12-13-17;
- FNA0025** : FIGG.1-3-4-5-6-7-9-10-17;
 FNA0031 : FIGG.1-3-4-5-6-7-9-10-18;
 FNA0033 : FIGG.2-8;
 FNA0034 : FIGG.1-3-4-5-6-9-10;
- FNA0035** : FIGG.1-3-4-5-6-8-9-10-14;
 FNA0036 : FIGG.2-3-4-5-6-9-10;
 FNA0037 : FIGG.2-3-4-5-6-8-9-10-14;
 FNA0041 : FIGG.1-3-4-5-6-7-9-10;

Pos. N.	Code Codice	MODIFICATIONS-MODIFICHE-ÄNDERUNGEN-MODIFICACIÓN			Up to serial nr. Fino a matricola
		SIMBOLS SIMBOLI	△	▲	

07 - 03

Pos. N.	DESCRIPTION DESCRIZIONE	Quantity (Q.tà)			8	SHEAT <small>{4L.06A-4LT.07A-6LT.04A-6LI.01A-4E.30A-4LTE.31/32A}</small>	4	4	16	PIPE	1	1	23	PLUG	1	1
		703	704	706												
1	PIPE		1		8	SHEAT (FNA0035-37)	1	1	17	PIPE	1		24	GASKET	1	1
2	PIPE			1	9	FUEL FILTER ASSY	1	1	18	PIPE	1		25	PLUG (FNA0018)	2	
3	SCREW	2	2		10	NUT	2	2	19	PIPE		1	26	GASKET (FNA0018)	2	
4	SPACER	2	2		11	FUEL FILTER ASSY	1		20	FILTER ELEMENT SET	1	1	27	FILTER ELEMENT SET	1	
5	BRACKET	1	1		12	SCREW	4		21	SCREW	1					
6	SCREW	2	2		13	BRACKET	1		21	GASKET	1					
7	PIPE	1	1		14	SHEAT	1	1	22	SCREW	1	1				
					15	FUEL FILTER ASSY	1	1	22	GASKET	1	1				