




GRUPPI COPERCHIO ANTERIORE - Front cover groups

COD0017: FIGG.1-2-3-4-5-6-8-9-10-11-13-15-16-17-18-19-20-21-22-25-26-31-32-33-38;
COD0018: FIGG.1-2-3-4-5-6-7-9-10-11-12-13-14-16-17-18-19-20-21-22-25-26-31-32-33;
COD0024: FIGG.1-2-3-4-5-6-7-9-10-11-12-14-15-16-17-18-19-20-22-25-26-31-32-33-34-35-36-37-38;
COD0025: FIGG.1-2-3-4-5-6-7-9-10-11-12-13-14-16-17-18-19-20-21-22-25-26-31-32-33-38;
COD0029: FIGG.1-2-3-4-5-6-7-9-10-11-12-13-14-16-17-18-19-20-21-22-25-26-31-32-33-39;

MODIFICATIONS MODIFICHE ÄNDERUNGEN-MODIFICACIÓN					
Pos. N.	Code Codice	SIMBOLS SIMBOLI			Up to serial nr. Fino a matricola
		☐	☐	☐	EC

Pos. N.	DESCRIPTION DESCRIZIONE	Quantity (Q.tà)				8					17					26				
		754																		
						8	LUBRIFICATION PIPE	1			17	FRONT SEAL RING	1			26	DOWEL	2		
						9	GASKET	1			18	GEAR	1			27	SUPPORT	1		
						10	ADAPTOR	1			19	DOWEL	2			28	O RING	1		
1	SCREW	13				11	GASKET	2			20	GASKET	1			29	HUB	1		
2	O RING	1				12	SCREW	1			21	COVER	1			30	GASKET	1		
3	PIN BEARING	1				13	CLIP	1			22	SCREW	6			31	FRONT COVER	1		
4	RING	2				14	CLIP	1			23	BALL BEARING	2			32	GASKET	1		
5	GASKET	2				15	CLIP	1			24	GEAR	1			33	PLUG	1		
6	UNION	2				16	SCREW	1			25	GASKET	1			34	HUB	1		
7	LUBRIFICATION PIPE	1																		