




GRUPPI BASAMENTI - Crankcases groups

BAS0009: FIGG.22-23-24-25-26-30-33-38-39-40-45-46-47-48-49-50-51-52-53-54-55-58-62-63-67-70-71-74-77:

BAS0010 : FIGG.1 2 3 11 18 30 33 38 43 44 48 49 50 51 52 53 54 55 57 60 67 70 71 74 79;

BAS0014 : FIGG.1-2-3-12-18-30-33-38-43-44-48-49-50-51-52-53-54-57-60-67-70-71-74-79;

BAS0018 : FIGG.1-2-3-11-14-15-16-17-33-38-42-44-48-49-50-51-52-53-54-55-57-60-67-70-71-74-79-82:

BAS0019 : FIGG.1-2-3-7-12-14-15-16-17-38-42-44-48-49-50-51-52-53-54-55-57-60-67-70-71-74-79-82; **BAS0022** : FIGG.1-2-3-11-18-30-33-38-43-44-48-49-50-51-52-53-54-55-57-60-67-70-71-74-79;

[illegible]

Pos. N.	DESCRIPTION DESCRIZIONE	Quantity 754	(Q.tà)
8	BUSHING	1	
9	PLUG	4	
10	PLUG	5	
11	CRANKCASE ASSY	1	
12	CRANKCASE ASSY	1	
13	BUSHING -0.00	2	
14	O RING	3	
15	DOWEL	3	
16	BALANCE SHAFT ASSY	1	
17	SCREW	6	
18	PLUG	3	
19	BUSHING	1	
20	BUSHING ASSY -0.25	1	
21	BUSHING ASSY -0.00	1	
22	WASHER	3	
23	SCREW	2	
24	SCREW	1	
25	DRIVING GEAR ASSY	1	
26	CRANKCASE ASSY	1	
27	BUSHING -0.25	2	
28	BUSHING ASSY -0.00	1	
29	BUSHING ASSY -0.25	1	
30	CONN.ROD KIT 4 CYLINDER	1	
31	SCREW	8	
32	BUSHING ASSY -0.00	4	
33	BUSHING ASSY -0.25	4	
34	BUSHING	4	