




GRUPPI BASAMENTI - Crankcases groups
BAS0009 : FIGG.22 23 24 25 26 30 33 38 39 40 45 46 47 48 49 50 51 52 53 54 55 58 62 63 67 70 71 74 77;
BAS0010 : FIGG.1 2 3 11 18 30 33 38 43 44 48 49 50 51 52 53 54 55 57 60 67 70 71 74 79; **BAS0014** : FIGG.1 2 3 12 18 30 33 38 43 44 48 49 50 51 52 53 54 57 60 67 70 71 74 79;
BAS0018 : FIGG.1 2 3 11 14 15 16 17 33 38 42 44 48 49 50 51 52 53 54 55 57 60 67 70 71 74 79 82;
BAS0019 : FIGG.1 2 3 7 12 14 15 16 17 38 42 44 48 49 50 51 52 53 54 55 57 60 67 70 71 74 79 82; **BAS0022** : FIGG.1 2 3 11 18 30 33 38 43 44 48 49 50 51 52 53 54 55 57 60 67 70 71 74 79;

MODIFICATIONS MODIFICHE ÄNDERUNGEN MODIFICACIÓN				
Pos. N.	Code Codice	SIMBOLS SIMBOLI	Up to serial nr. Fino a matricola	
		△ ▲ □ EC		

Pos. N.	DESCRIPTION DESCRIZIONE	Quantity (Q.tà) 75A	76	77	78	79	80	81	82	6	1								
			SPRING PIN	SHAFT BRACKET ASSY WITH BUSHING	SHAFT BRACKET ASSY WITHOUT BUSHING	SHAFT BRACKET ASSY WITH BUSHING	SHAFT BRACKET ASSY WITHOUT BUSHING	SCREW	CONN.ROD KIT 4 CYLINDER										
69	THRUST WASHER +0.20	1																	
70	SEAL RING	1																	
71	O RING	1																	
72	SCREW	1																	
73	SHIM RING	1																	
74	NUT	6																	
75	STUD	6																	