

GRUPPI FILTRI ARIA - *Air filter groups*

FAR0036: FIGG.3-4-5-6-7-8-9-11-19-20-21-25-27-35; **FAR0039**: FIGG.3-4-7-11-22-23-24-26-27-28-30-31-36-37-38-39-40-41-42-43-44-45-46-47-48;

FAR0041: FIGG.3-4-5-6-7-8-9-10-11-12-18-19-20-21; **FAR0042**: FIGG.3-4-5-6-7-8-9-11-12-19-20-21-25-35;

FAR0043: FIGG.1-2-5-6-7-8-9-10-11-12-18-19-20-21; **FAR0044**: FIGG.1-2-5-6-7-8-9-11-12-19-20-21-25-35; **FAR0046**: FIG.21;

MODIFICATIONS-MODIFICHE-ÄNDERUNGEN-MODIFICACIÓN

Pos. N.	Code Codice	SIMBOLS SIMBOLI △	▲	⧄	EC	Up to serial nr. Fino a matricola
2	4 161 0034	X		X		
3	4 161 0036	X		X		
7	2 051 2892	X		X		

Pos. N.	DESCRIPTION DESCRIZIONE	Quantity (Q.tà) 703	704	706		Pos. N.	DESCRIPTION DESCRIZIONE	703	704	706		Pos. N.	DESCRIPTION DESCRIZIONE	703	704	706		Pos. N.	DESCRIPTION DESCRIZIONE	703	704	706	
1	SHEAT	1				9	SCREW	2	2			19	CLAMP	2	2			29	CAP			1	
2	CLAMP	1				10	SCREW	2				20	SHEAT	1	1			30	SHEAT			1	
3	CLAMP	1		3		11	SPACER	2	2	2		21	AIR CLEANER	1	1			31	SHEAT			1	
4	SHEAT	1				12	SCREW	2				22	WASHER			2		32	FILTER ELEMENT			1	
5	NUT	4				13	CAP	1				23	WASHER			2		33	FILTER CAP ASSY			1	
6	WASHER	4				14	FILTER ELEMENT	1				24	SCREW			2		34	CLAMP			1	
7	AIR FILTER SUPPORT	1				15	FILTER CAP ASSY	1				25	SCREW		2			35	SHEAT		1		
8	VIBRATION DAMPER	2				16	CLAMP	1				26	SCREW			4		36	AIR CLEANER			1	
						17	CLOGGING GAUGE	1				27	SCREW		2	2		37	PLUG			1	
						18	SHEAT	1				28	CLAMP			2		38	CLAMP			2	